


EARTHEN ARCHITECTURE IN THE WORLD

POURED EARTH

The soil, in a liquid state, is poured like concrete into formworks. The soil characteristics must be very sandy or gravely and should be stabilised. This technique is a new development and is very seldom used. The reason is that the high water content of the soil will induce a lot of shrinkage when it will dry. Thus the wall will crack and generally a lot.



Courtesy CRATerre -EAG



New Zealand (Photo Milles Allen)



Brasil, Rio de Janeiro - 1949 (Photo Unknown)



New Zealand (Photo Milles Allen)